# **AlphaTec**®

### **Glove Connector**

Providing an integrated chemical protection solution

The simple solution for attaching chemical gloves to coveralls

- Innovative design utilising the latest polymer technology
- Creates a liquid tight seal between glove and cuff
- Consistent and reliable alternative to taping
- Quick and easy fit improves productivity
- Works with a wide variety of chemical glove thicknesses
- Ribbed cone and collar for secure attachment
- AlphaTec® Advanced Chemical Protection

#### **Industries**

- Agriculture
- Chemical
- Construction
- Food Manufacturing
- Life Sciences
- Oil and Petrochemical
- Waste Disposal

#### **Applications**

- Caustic clean downs
- Chemical handling/ transportation
- · Industrial tank cleaning
- Paint spraying
- Sewage purification inspections
- Solvent degreasing and parts cleaning



Tested in accordance with ISO 17491-3:2008 - Determination of resistance to penetration by a jet of liquid (jet test)

Coverall	Ansell Glove Brand & Material Technology		
MICROGARD® 2300 PLUS	MICROFLEX® 93-260	0.198mm	Neoprene & Nitrile
	AlphaTec® 58-530	0.33mm	Nitrile
MICROCHEM® 3000	ChemTek™ 38-612	0.3mm	Butyl/Viton
	Neotop™ 29-500	0.7mm	Neoprene
MICROCHEM® 5000	Scorpio® 09-924	1.5mm	Neoprene



## AlphaTec®

### **Glove Connector**

#### **INSTRUCTIONS FOR USE:**




**Step 1** - Push the narrow end of the ribbed grey cone into the glove.



**Step 2** - Ensure the glove fully covers the grey cone.



Step 3 - Push the glove with the cone fitted up into the sleeve making sure the cone within the glove is fully covered by the sleeve as shown in step 4. If double sleeve, use the outer.



Step 4 - Align the small finger of the glove with the seam on the sleeve of the coverall as this will ensure the glove is in the correct orientation.



Step 5 - Pass the glove through the AlphaTec\* green outer ring. Note ring orientation - the logo on the ring needs to be as shown above.



Step 6 - Hold the sleeve of the coverall as shown and check there are minimal creases on the sleeve end and gently push the AlphaTec\* green collar up the sleeve so that the sleeve cuff is exposed and the collar is beginning to tighten on the inner glove cone.



Step 7 - Using both hands push the AlphaTec\* ribbed green collar further up the sleeve until tightly locked in position. Ensure outer ring is tightened as far as possible to provide a secure fit.



Step 8 - Pull on the glove and sleeve to check the AlphaTec\* Glove connector is fitted correctly and if loose then repeat Step 7.

**Product Code:** 

AC01P-00070-00

**Patent Pending** 

#### For additional information visit us at www.ansell.com, or call us at:

#### Europe, Middle East & Africa Region

Ansell Healthcare Europe NV Riverside Business Park Blvd International, 55 1070 Brussels, Belgium +32 2 528 74 00 +32 2 528 74 01

#### **Asia Pacific Region**

Ansell Global Trading Center (Malaysia) Sdn Bhd Prima 6, Prima Avenue Block 3512, Jalan Teknokrat 6 63000 Cyberjaya Selangor, Malaysia T: +60 3 8310 6688 F: +60 3 8318 6699

#### North America Region

Ansell Healthcare Products LLC 111 Wood Avenue South, Suite 210 Iselin, NJ 08830, USA +1 800 800 0444 +1 800 800 0445

#### Latin America & Caribbean Region

Ansell Commercial México S.A. de C.V.
Bvld. Bernardo Quintana No. 7001-C,
Q7001 Torre II.
Suites 1304, 1305 y 1306.
Col. Centro Sur, C.P. 76079
Querétaro, Qro. México
T: +52 442 248 1544 / 248 3133

#### Australia

Ansell Limited Level 3, 678 Victoria Street, Richmond, Vic, 3121 Australia +61 1800 337 041 +61 1800 803 578



Ansell